





STEP 1: Perform a Zero Calibration

1. Confirm the belt is running empty
2. Press the zero calibration button 
3. When it is finished, press the enter button  a few times until you reach the main run screen
4. Confirm the rate is 0 and we are not adding or subtracting any weight


STEP 2: Material Test Calibration

1. Write Down starting weight or press the Clear Weight  button twice to reset the accumulated weight to zero
2. Run material over the scale into a truck. *Weigh the truck Empty to get a good tare weight
3. Write down the Belt Scale weight and the Certified Scale weight. Repeat test 3 times to confirm repeatability
4. If the scale is repeatable, add up the total of all 3 Belt Scale results. Then add up the total of all 3 Truck Scale results
5. Press the menu key 
6. Navigate to Calibration  using the arrow keypad  and press enter 
7. Navigate to Material Test  and press enter 
8. Here you will enter your total Belt Scale weight.
9. Press Enter  on BELT SCALE WEIGHT


10. Now you will be in the digital keypad section



11. Use the arrow keypad  to enter in the total Belt Scale weight

12. Once the weight is entered you will have to scroll to the digital enter button and select enter  to continue to the next screen





13. Press the enter button  again to proceed to the next screen


14. Now press Enter  on CERTIFIED WEIGHT


15. Now you will be in the digital keypad section



16. Use the arrow keypad  to enter the total Certified Scale weight

17. Once the weight is entered you will have to scroll to the digital enter button and select enter  to continue to the next screen

18. Press the enter button  again to begin the calibration process.

19. It will now read 100% complete, Press the enter button  three times to confirm calibration results and return to the main run screen

20. Calibration is complete