












STEP 1: Perform a Zero Calibration

1. Confirm the belt is running empty
2. Press the zero calibration button 
3. When it is finished, press the enter button  a few times until you reach the main run screen
4. Confirm the rate is 0 and we are not adding or subtracting any weight

STEP 2: Test Weight Calibration

1. Install Test Weights
2. Confirm belt is running
3. Press the MENU key 
4. Using the keypad  navigate to CALIBRATION  and press enter 
5. Navigate to TEST WEIGHT  and press enter 
6. Here you will enter your test weight value and navigate to the digital enter button to continue 
7. Press enter  to Start Calibration
8. Once 100% complete, Press the enter button  a few times to confirm calibration results and return to the main run screen
9. Calibration is complete.