




To meet CE requirements for emissions pass all three wires (Line, Neutral, Earth) through the core of the provided Ferrite Bead and then terminate normally. Call Belt-Way Scales for any questions or if you need assistance at 800-441-4237.





Belt-Way Scales

In Motion Weighing Solutions



8040-0026-0M Rev A 04/21