

## Step-On Can Trash Bag Installation and Cleaning Instructions

### Installing the Trash Bag

1. Step on and hold the foot pedal to raise and hold the step-on can lid open.
2. Raise both bag loops about 30 degrees.
3. Place the trash bag in the step-on can between the bag loops.
4. Wrap the trash bag around on top of both bag loops.
5. Lower the bag loops (with the bag wrapped around the loops) to secure the trash bag in the step-on can.
6. Release the foot pedal to lower the lid.
7. Your Step-On can is ready to use.



### Removing the Trash Bag

1. Step on and hold the foot pedal to raise and hold the step-on can lid open.
2. Raise both bag loops and unwrap the trash bag from the bag loops.
3. Lift the trash bag from the step-on can and secure closed with twist-ties or other means.
4. Install a new trash bag following the steps above.

### Cleaning Your Step-On Can

- When cleaning, only use a damp soft cloth or a plastic scouring pad for a cleaning cloth.
- Use a neutral dish soap or a mild non-abrasive detergent and lukewarm water.
- Do not use acetone, paint thinner, or other volatile solvents for cleaning.
- Do not use things that will scratch the surface, such as steel pads, wire brushes, and scrapers.
- For hard-to-clean spots, use standard household cleansers and a soft bristle brush on troublesome spots or stains. Pre-soak heavy, dried-on soil, if needed.
- If used in food preparation areas, clean frequently to avoid build-up.