



CARDINAL®

SB600 Wireless Card Firmware Update Instructions

Required Items:

- **Firmware File** – Download from *SB600 Resource Type > Software*
- **nControl V2 App** – Available for download on the **Apple App Store** or **Google Play Store**
- **Mobile Device** – iPhone, iPad, or Android phone/tablet

Procedure:

1. Download Firmware:

- Access the official SB600 support page on your mobile device.
- Locate the latest firmware version.
- Tap the 'download' button to save the file to your mobile device.

2. Connect to SB600:

- Connect to the SB600 with the nControl V2 App (IOS or Android) and go to the advanced settings.

3. Update Firmware:

- In the Advanced settings, select Update Firmware. *This will flag the SB600 to start the firmware update process.*

4. Power Cycle Remote Display:

- Turn off the SB600.
- Wait for 10 seconds.
- Turn the SB600 back on to prepare for the update.

5. Connect to Wi-Fi Network:

- After the SB600 reboots, it will broadcast a Wi-Fi network SSID. *This is typically named 'SB600'.*
- Open the Wi-Fi settings on your mobile device.
- Connect to the SB600 network.

6. Upload and Update Firmware:

- Open a web browser on your mobile device.
- Enter the address 2.2.2.2 into the browser's address bar.
- Navigate to the firmware update section.
- Select the downloaded firmware file.
- Tap 'Upload' to start the update process.



Please ensure your mobile device remains connected and powered during the update process.

Cardinal Scale Mfg. Co.

102 E. Daugherty, Webb City, MO 64870 USA

Ph: 417-673-4631 or 1-800-641-2008

Fax: 417-673-2153

www.cardinalscale.com

Printed in USA

3601-0845-0M Rev A 10/25

Technical Support: 1-866-254-8261

E-mail: tech@cardet.com