



225-DLC CONTROLLER SOFTWARE UPDATE INSTRUCTIONS

1. Download the 225-DLC Controller Software update package 225DLC_x_yy_zzz.zip (where x_yy_zzz is the software version) from the dealer-protected software section of CardinalScale.com. *Download the file from CardinalScale.com by navigating to 225 Navigator > Resource Type > Software >.*
2. Power off the 225D.
3. Remove the 14 acorn nuts securing the 225D rear panel assembly to the main housing.
4. Lift the rear panel from the main housing, taking care not to stretch the cable and wires between the panel and main housing. Lay the rear panel aside.
NOTE: You may need to loosen the gland connectors for the I/O cables to allow enough slack in the cable and wires to avoid stretching them.
5. Connect the USB cable (Type A to mini-B) to the PC and DLC card.
6. Power on the 225D.
7. Run the 225DLC.bat file that was unzipped previously.
8. If " **ERROR** " appears on the PC check that the USB cable is connected to the PC and option card. Power the 225D off, wait a minute, power on, then try again.
9. The update will take several minutes.
10. Do not disconnect until the "**Press any key to continue...**" display appears on the PC.
11. Power off the 225D.
12. Disconnect the USB cable from the DLC card and the PC.
13. Secure the 225D rear panel with the 14 acorn nuts removed earlier.
14. Follow a diagonal pattern when tightening the acorn nuts.
15. Power on the 225D. The updated card version will show on the startup screen.



Cardinal Scale Mfg. Co.

102 E. Daugherty, Webb City, MO 64870 USA

Ph: 417-673-4631 or 1-800-641-2008

Fax: 417-673-2153

www.cardinalscale.com

Technical Support: 1-866-254-8261

E-mail: tech@cardet.com