



## Mechanical Baker's Dough Scale Instruction Sheet

### PRODUCT SPECIFICATIONS

Model	Capacity	*Scoop and Jar	Weight Pack P/N	Stainless Steel	Enamel
1001TB / 1001T2B	16 lb	X	1WP100X		X
1001TBKG	8 kg	X	1WK200X		X
1001TBNS / 1001T2BNS	16 lb		1WP100X		X
1002TB / 1002T2B	8 lb	X	1WP250X		X
1002TBKG	5 kg	X	1WK100X		X
1002TBNS / 1002T2BNS	8 lb		1WP250X		X
1051TBS	16 lb	X	1WP100X	X	
1051TBSKG	8 kg	X	1WK200X	X	
1052TBS	8 lb	X	1WP250X	X	
1052TBSKG	5 kg	X	1WK100X	X	

Cardinal Scale reserves the right to improve, enhance, and modify features and specifications without prior notice.

\* All models with Scoop and Jar include:

P/N 6100-0002, SCOOP, PLASTIC.

P/N 6100-0005, JAR W/LID, POLYPROPYLENE.

### UNPACKING INSTRUCTIONS

Check for any damage to carton incurred in shipping and for damage to scale when unpacked. If the scale has been damaged, place a claim with the carrier. It is the responsibility of the purchaser to file all claims for any damages or loss incurred during transit. Use the original carton and shipping material if possible to return the scale.

1. Open carton and remove packing and/or the scoop and counterweight jar.
2. Remove the inner scale carton and open. DO NOT use blade as you could scratch the scale.
3. Remove scale from carton by lifting on center of packing and pulling straight up.
4. Remove the weights from the outside of packing material.
5. Carefully remove the packing from either side of scale. Be careful as weights inside could fall out.
6. Remove weights from inside of packing.

### OPERATING INSTRUCTIONS

#### Adjusting the Counterweight

1. Unscrew top from counterweight.
2. Place counterweight, top, and scale pan on respective sides.
3. Fill counterweight with sugar or salt until balance is achieved.
4. Secure top to counterweight.

#### To Move Poise

To move poise, lift up to clear notches on beam, and slide to desired position and release.

### CARE AND CLEANING OF SCALE

- **DO NOT** subject the weight plates to sudden shocks.
- **DO NOT** use abrasive cleaners, acetone, or other volatile solvents for cleaning scale.
- **DO** clean the scale using a damp soft cloth and mild detergent.
- **DO** avoid areas where the scale might be exposed.