



825-DLC CONTROLLER SOFTWARE UPDATE INSTRUCTIONS

Items Required

- PC with Microsoft Windows OS and USB port.
- Type-A to micro USB cable
- 825-DLC Card update zip file downloaded from the dealer-protected software section of CardinalScale.com. *Download the file from CardinalScale.com by navigating to 825 Spectrum > Resource Type > Software >.*

Updating the 825-DLC Card

1. Download the 825-DLC Controller Software update zip file and then unzip the update zip file to a location on the PC such as Downloads.
2. Power off the 825.
3. Connect the Type-A to micro USB cable between the PC and the 825-DLC card.
4. Power on the 825.
5. Run the 825DLC.bat file that was unzipped previously.
6. If **"ERROR"** appears on the PC check that the USB cable is connected to the PC and the 825-DLC card. Power the 825 off, wait a minute, power on, then try again.
7. The update will take several minutes.



Type-A to Micro USB Cable



IMPORTANT! Do not disconnect the USB cable from the PC and the 825-DLC card until the **"Press any key to continue..."** display appears on the PC.

8. Power off the 825 and disconnect the USB cable from the 825-DLC card and the PC.
9. Power on the 825. The updated card version will show on the startup screen.

Cardinal Scale Mfg. Co.

102 E. Daugherty, Webb City, MO 64870 USA

Ph: 417-673-4631 or 1-800-641-2008

Fax: 417-673-2153

www.cardinalscale.com

Technical Support: 1-866-254-8261

E-mail: tech@cardet.com