



## DRIVER INSTALLATION INSTRUCTIONS FOR INDICATOR'S USB PORT

1. Connect USB cable between indicator and your PC.
2. Ensure jumper settings are as follows:
  - a. 225 indicator – J3 & J4 set to USB
  - b. 205/210 indicator – J4 & J5 set to USB
3. Power up the indicator. If the indicator was already turned on then power-cycle the indicator.
4. Open up the Device Manager.
  - a. Left click on the Start button.
  - b. Right click on Computer.
  - c. Left click on Properties.
  - d. Left click on Device Manager.
5. Locate the new USB device. It should be labeled "Unknown Device" under the USB controllers.
6. Right click on the device then left click on Update Driver.
7. When the driver installation wizard appears, select the option to "Install Driver Manually."
8. Left click on the option to "pick from a list of device drivers."
9. The wizard will now display a list of compatible drivers. Left click the Have Disk button.
10. Another window will appear where you can type in the driver directory. Left click the Browse button.
11. Locate and select the driver provided named "usb2ser.inf" then click the Open button.
12. The driver's file location has now been input for you. Press the OK button.
13. Left click the Next button.
14. Once the driver completes installing, left click the Finish button.