

204 INDICATOR



LARGE 1 INCH HIGH 6-DIGIT LCD DISPLAY

GROSS, TARE, NET OPERATION

BI-DIRECTIONAL SERIAL PORT

CUSTOM LABEL / TICKET FORMAT

STAINLESS STEEL ENCLOSURE

AC OR DC
BATTERY POWER

AUTO SHUTOFF AND SLEEP MODES

Ideal for floor and bench scales, Cardinal's 204 indicator is furnished complete with motion detection and a serial printer port that allows weigh data printing. The 204 is suitable for desk or wall mount and can be adjusted to any angle for easy viewing with its 1" high LCD.

CUSTOM TICKET SLOT AVAILABLE

Model 204 Digital Weight Indicator



Whether you require a permanent installation or a portable scale on the move, the 204 can be powered three ways:

- **AC Power**
- Alkaline batteries
- Rechargeable Ni-Cad batteries





Format and print custom tickets with nControl software, designed exclusively by Cardinal, allowing complete setup of the 200 series indicators from a PC.



A VERSATILE, ECONOMICAL CHOICE!

Protection Rating:NEMA 12/IP55 stainless steel

Load Cells: Up to 4, 350 ohm minimum resistance

alkaline or rechargeable Ni-Cad batteries

Selectable Parameters:Decimal point, filtering, weight, sample rate, baud rate

Keypad: Color-coded membrane type, 7 keys

Standard I/O:.....(1) bi-directional RS232

Zero Tracking: ______1 to 9d selectable Conversion Rate:......10 per second, max **Sensitivity:**1.2µV per division



Sold By:



Cardinal Scale reserves the right to improve, enhance, or modify features and specifications without prior notice.

Cardinal Scale Manufacturing Co. 203 E. Daugherty, Webb City, MO 64870 USA

Ph: 417-673-4631 or 800-441-4237 • Fax: 417-673-5001

www.CardinalScale.com