



- Lightweight, Portable Scales
 with Carrying Handle
- Legal for Trade Certified (NTEP, OIML, Measurement Canada)
- 2 Capacities and 2 Different Weight Indicators Available
- Black Slip-Resistant Mat and Bubble Level
- Low-Profile Platform: 18 in W x 14 in D x 2 in H / 46 cm W x 36 cm D x 6 cm H
- Electrostatic Powder Paint Coating for Long Life
- Available in up to 600 lb / 270 kg Capacity
- Display May be Set on Floor or Table or Mounted on the Wall
- Ticket Printing Available through -205 Models
- Keypad Tare

GP-400-185B

GP-400-205





STORM

DIGITAL LOW-PROFILE SCALES WITH INTEGRAL CARRYING HANDLE

Cardinal Scale's NTEP legal-for-trade certified GP-400/684P scales are lightweight and portable with almost limitless uses. Featuring a roomy 18 x 14-inch steel platform with bakedon, long-lasting powder-coat paint, and nonskid rubber mat with bubble level, these scales are portable with a built-in carrying handle. They offer keypad tare, auto power off, digital speed and accuracy, vivid readouts, and the indicator may be set on a table or floor or even mounted on the wall for readouts.



Model	GP-400-185B	GP-400-205	684P-185B	684P-205	
Capacity	400 lb x 0.2 lb / 180 kg x 0.1 kg	400 lb x 0.2 lb / 180 kg x 0.1 kg	600 lb x 0.2 lb / 270 kg x 0.1 kg	600 lb x 0.2 lb / 270 kg x 0.1 kg	
Display	1-in-high backlit green LCD	0.6-in-high red LED	1-in-high backlit green LCD	0.6-in-high red LED	
Power	6 AA batteries (not included) or 12 VDC at 1A AC power adapter	100-240 VAC (50/60 Hz) at 0.4A max	6 AA batteries (not included) or 12 VDC at 1A AC power adapter	100-240 VAC (50/60 Hz) at 0.4A max	
Platform Dimensions	18 in W x 14 in D x 2 in H / 46 cm W x 36 cm D x 6 cm H				
Construction	Mild steel with white powder-coat paint				
Load Cells	Four 250-lb shear beam				
Shipping Weight	19 lb / 9 kg				
Country of Origin	USA				
Indicator Feature		185B		205	
Power Requirements		6 AA Batteries		AC	
Battery Power Optional B		Battery operation is standard		N	
Enclosure Construction		ABS	Sta	Stainless Steel	
	IP Rating	IP66		IP66	

Ν

Υ

Υ

1

1-inch-high Backlit Green LCD

7-Key Membrane

Ν

Ν

Ν

Ν



USB Interface

Display Type

Counting Feature

Push Button Tare

RS232 Serial Ports

Number of Keys/Keypad Type

Optional Ethernet/Wireless

Selectable Key Lockout

nControl Compatible

Remote Digital Inputs

Carainal Scale Manujaciuring Co. 102 E. Daugberty, Webb City, MO 64870 USA Pb: 417-673-4631 or 800-441-4237 • Fax: 417-673-2153 www.CardinalScale.com Cardinal Scale reserves the right to improve, enhance, or modify features and specifications without prior notice.

SOLD BY:

Υ

Ν

Υ

4

0.6-inch-high Red LED

7-Key Membrane

γ

Y (2 tickets)

Υ

Y (8)