



Cardinal Scale
model HSDC-500
digital hanging scale
with pushbutton tare

HSDC Series

Digital Hanging Scales



LEGAL FOR TRADE

Class III certificate
All HSDC models are NTEP
except model HSDC-500



Stainless Steel Eyehook
and Hook Included for
Versatile Weighing Use

- 1-inch-High Bold LCD Readouts for Easy Visibility
- Aluminum Alloy Enclosure for Lightweight Strength
- Up to 500-lb and 100-kg Capacities Available
- 9 Different Models to Select From
- Battery Powered for Convenient Portable Weighing

Cardinal Scale's HSDC Series Digital Hanging Scales

Fishing • Curbside Recycling Collection • Butchery/Meat Processing • Industrial Applications • Supermarkets



Powered by 6 C batteries for completely portable weighing (not included)
Auto Shutoff and Sleep Mode extend battery life



1-inch/25-mm-high bold LCD display
Lightning-fast and accurate digital readouts

Model HSDC-20KGP includes stainless steel bowl
Stainless steel bowl measures 13.7 in diameter x 4.4 in H / 34.8 cm diameter x 11.2 cm H



| HSDC-20 | HSDC-40 | HSDC-100 | HSDC-200 | HSDC-500 | HSDC-20KG/ HSDC-20KGP | HSDC-40KG | HSDC-100KG |
|--|----------------|--|----------------|----------------|---|----------------|-------------------|
| 20 lb x .01 lb | 40 lb x .02 lb | 99.95 lb x .05 lb | 200 lb x .1 lb | 500 lb x .2 lb | 20 kg x .01 kg HSDC-20KGP features stainless steel pan | 40 kg x .02 kg | 99.95 kg x .05 kg |
| Scale Dimensions | | Width: 8.5 in / 21.6 cm Depth: 5.1 in / 13.0 cm Height: 4.3 in / 10.9 cm | | | | | |
| Overall Dimensions (with hooks) | | Width: 8.5 in / 21.6 cm Depth: 5.1 in / 13.0 cm Height: 14.0 in / 35.6 cm (including eyehook and hook) | | | | | |
| LCD Display Dimensions | | Width: 3.3 in / 8.4 cm Height: 1.1 in / 2.8 cm | | | | | |
| LCD Digit Size | | Width: 0.5 in / 1.3 cm Height: 1.0 in / 2.5 cm | | | | | |
| Product Weight | | 5.8 lb / 2.6 kg (10 lb / 4.5 kg with model HSDC-20KGP's stainless steel bowl and hanging assembly) | | | | | |
| Shipping Weight | | 7.2 lb / 3.3 kg (including packaging) | | | | | |
| Power | | 6 C size alkaline batteries (not included) | | | | | |
| Operating Temperature | | +14° to 104°F (-10° to +40°C) | | | | | |
| Zero | | Established during setup and maintained automatically to ± 1/4 graduation | | | | | |
| Auto Zero Range | | 5 and 0 through 9 graduations | | | | | |
| Calibration Method | | Digital, keypad entered; calibration stored in nonvolatile memory | | | | | |
| Tare | | Push button, 100% of full scale capacity | | | | | |
| Annunciators | | Center of zero, motion, net, low battery, over capacity | | | | | |
| Buttons | | ON/ZERO, NET, TARE, GROSS, OFF | | | | | |
| Load Cell | | Cardinal Scale model CMBC constant moment beam cell | | | | | |
| Sample Rate | | 1 - 12 samples per second, selectable | | | | | |
| Auto Shut-off | | Power saving mode selectable from 1 to 9 minutes | | | | | |
| NTEP Approval | | 03-030 Accuracy Class III (applies to all HSDC models except HSDC-500) | | | | | |

Cardinal Scale reserves the right to improve, enhance or modify features and specifications without prior notice. All registered trademarks are the property of their respective owners.

 **Cardinal**[®]
Cardinal Scale Manufacturing Co.
203 E. Daugberty, Webb City, MO 64870 USA
Ph: 417-673-4631 or 800-441-4237 • Fax: 417-673-5001
www.CardinalScale.com

Mobile: m.cardinalscales.com

SOLD BY: