



Whether it will go in a stockyard, processing plant, or ranch, if you deal in the weighing of livestock, Cardinal has a heavy-duty scale to weigh your animals.



- Fewer Levers And Parts Less Wear And Tear
- Double-Link Suspension Bearings
- Concrete or Wood Deck Models
- Simple Pit Design
- "Legal For Trade"



LEGAL FOR TRADE

Livestock rack not included.

Electro-Mechanical Livestock Scales

CONCRETE		
PLATFORM SIZE	CAPACITY	SHIP WEIGHT
12' x 8' (3.6 m x 2.4 m)	5 ton	1,349 lb / 611 kg
14' x 8' (4.2 m x 2.4 m)	5 ton	1,460 lb / 622 kg
16' x 9' (4.9 m x 2.7 m)	10 ton	2,273 lb / 1,031 kg
18' x 9' (5.4 m x 2.7 m)	10 ton	2,839 lb / 1,287 kg
22' x 9' (6.7 m x 2.7 m)	10 ton	3,017 lb / 1,368 kg
30' x 14' (9.1 m x 4.2 m)	10 ton	6,250 lb / 2,835 kg
30' x 14' (9.1 m x 4.2 m)	15 ton	6,236 lb / 2,828 kg
26' x 14' (7.9 m x 4.2 m)	20 ton	5,997 lb / 2,720 kg
	PLATFORM SIZE 12' x 8' (3.6 m x 2.4 m) 14' x 8' (4.2 m x 2.4 m) 16' x 9' (4.9 m x 2.7 m) 18' x 9' (5.4 m x 2.7 m) 22' x 9' (6.7 m x 2.7 m) 30' x 14' (9.1 m x 4.2 m) 30' x 14' (9.1 m x 4.2 m)	12' x 8' (3.6 m x 2.4 m) 5 ton 14' x 8' (4.2 m x 2.4 m) 5 ton 16' x 9' (4.9 m x 2.7 m) 10 ton 18' x 9' (5.4 m x 2.7 m) 10 ton 22' x 9' (6.7 m x 2.7 m) 10 ton 30' x 14' (9.1 m x 4.2 m) 10 ton 30' x 14' (9.1 m x 4.2 m) 15 ton

*Add "W" suffix for each model number to specify WOOD DECK.

Cardinal's Electro-Mechanical Livestock Scales are built with structural steel levers and seamless steel tubing providing extra strength and less weight. Doublelink suspension bearings eliminate platform shock prolonging the life of the scale. Pivots are tempered high-grade tool steel and, along with selfaligning bearings, are supported throughout their entire length. Interchangeable parts and simple pit design make installation and maintenance quick and easy. Electro-mechanical livestock scales have the advantages from both electrical and mechanical scale systems combined. With the dependability of the lever system and one Cardinal strain gauge load cell, weight indication can be located away from the scale platform.

Cardinal's Fully Electronic Livestock Scales provide easy top plate access to the load cells and bumper bolts. The low profile design 10" high reduces foundation costs to a minimum. The LSE model features stainless steel beam load cells and concrete deck design.

• Concrete Deck

• Easy To Install

• 10" Height

Cert. No. 97-043

LEGAL FOR TRADE

Cardinal

Livestock rack not included.

Full Electronic Low-Profile Livestock Scales

	CONCRETE DECK					
MODEL	PLATFORM SIZE	CAPACITY	SHIPPING WEIGHT	NUMBER OF SECTIONS	NUMBER OF MODULES	NUMBER OF LOAD CELLS
LSE1018	18' x 10' (5.4 m x 3 m)	10 ton	3,153 lb / 1,430 kg	2	1	4
LSE1020	20' x 10' (6 m x 3 m)	10 ton	3,500 lb / 1,587 kg	2	1	4
LSE1630	30' x 10' (9.1 m x 3 m)	16 ton	6,127 lb / 2,779 kg	3	2	6
LSE1635	35' x 10' (10.6 m x 3 m)	16 ton	7,148 lb / 3,242 kg	3	2	6

Cardinal Scale reserves the right to improve, enhance, or modify features and specifications without prior notice.

Sold By:



203 E. Daugherty, Webb City, MO 64870 USA Ph: 417-673-4631 or 800-441-4237 • Fax: 417-673-5001

www.CardinalScale.com