



## WEIGHT PRINTERS

### Ticket • Tape • Label • Continuous Form

Most of today's weighing installations require not only accurate weighing, but fast, accurate printing. Cardinal offers a variety of printers for most any need - simple or complex, we offer a variety of ticket-tape labels or continuous forms. All printers

are designed to connect to our family of weight indicators which can control and transmit valuable weight data in a fast orderly fashion, giving you longterm quality records.

*P400 Ticket Printer*



The P400 Ticket Printer is a high performance, multifunctional printer capable of printing a variety of tickets. Tickets can easily be inserted and removed. A long-life print mechanism and an easy-to-change ink cartridge allow frequent use with no sacrifice in speed or quality of printout.



*P240 Direct Thermal Printer*

If you require longevity, high quality, and thermal printer technology, the P240 is your answer. This high quality direct thermal printer is perfect for labeling, featuring a flip-up print head for easy media loading or cleaning, and producing high quality characters at 203 dots per inch. It prints up to 4" per second with a print width of 4". Interfacing to Cardinal indicators via a RS-232 serial port, the P240 can print lines, boxes and graphics.



Model P220



Model P240



Model P400



Model CTP-1



Model P600



Model P800



Model P900

### **P220 and P240**

The P220 and P240 high quality direct thermal printers are perfect for labeling, feature a flip-up print head for easy media loading or cleaning, and produce high quality characters at 203 dots per inch. The P220 has a print width of 2" and the P240 has a print width of 4". Both feature a print speed of up to 4" per second. Interfacing to Cardinal's indicators via a RS-232 serial port, they can print lines, boxes and graphics. If you require a high quality thermal printer, these models are your answer.

### **P400**

The P400 Ticket Printer is a multifunctional printer capable of printing a variety of tickets. This printer prints on the original and up to 4 copies. Tickets can easily be inserted and removed. Front panel controls permit tickets to be advanced, reversed, or released. Its long-life print mechanism and easy-to-change ink cartridge permit frequent use with no sacrifice in speed or quality of printout.

### **CTP-1**

Cardinal's CTP-1 Dot Matrix Ticket Printer prints up to 2.1 lines per second. Its features include insert ticket and multi copy printing. It interfaces with Cardinal indicators via a RS-232 serial port. Standard serial printer cable provided. Character size is 2.9 mm x 1.6 mm and the printer has 35 columns.

### **P600**

The P600 Tape Printer incorporates versatile on-board electronics and has a print speed of up to 30 receipts per minute. These are some of the key features that provide the basis for its ability to be tailored to the simplest or most complex printouts needed for applications such as process control, inventory control, and material handling installations. The printer can be configured for continuous eject tape or can provide individual receipt slips as needed for the weighing installation.

### **P800**

The P800 Deskjet Printer is excellent for printing reports from such applications as Cardinal's WinVRS software where full-color graphics reports are necessary. The detail is sharper and the print speed faster than other printer models. Connect via USB or parallel, and the USB connection allows two printers without having to buy additional computer hardware.

### **P900 and P900S**

The P900 and P900S Continuous Form Printers are ideal when detailed documents are required such as batching records, process control statistics, or truck weighing records. The durable 9-PIN print head, self-inking ribbon cartridge, and adjustable pin feed mechanism allows these printers to accept an assortment of paper types and sizes with a print speed of 300 CPS. The P900 Printer is furnished with a parallel input while the P900S is supplied with a serial input board.

Cardinal Scale reserves the right to improve, enhance or modify features and specifications without prior notice.

**Sold By:**



102 East Daugherty St., Webb City, MO 64870 USA  
Toll-Free: (800) 441-4237 E-mail: cardinal@cardet.com  
www.CardinalScale.com