





- SMALL FOOTPRINT: Occupies only a small fraction of the space needed for a full-length static truck scale
- AXLE WEIGHTS: Weighs axle weights plus total weight while the vehicle is in motion up to 20 mph
- SAVES TIME: Weighs vehicles without the need for the driver to stop saves time and traffic congestion
- QUALITY: Welded steel weighbridge designed for performance/longevity

Weight-In-Motion		
Axle	Weight	Counts
1 2 3 4 5	23780 17076 13117 12817 17564	Axles overwt
	0.405.4	Trucks overwt
TOT	84354	0
	-860 BZ	ESC) MENU

Cardinal's SWIM scale will capture individual axle weights plus the total gross weight while the vehicle is in motion.

www.CardinalScale.com

# SVIM

# SLOW-SPEED IN-MOTION SCALES

• SPEED: The SWIM scale will provide gross vehicle weights at speeds up to 20 mph.

Note: As speeds go up, accuracy will go down. 7-10 mph should be the target speed.

- ACCURACY: Provides gross vehicle weights within 1% at speeds less than 10 mph.
- COST SAVINGS: The SWIM provides a low-cost alternative to traditional static weigh scales.



## Load Cell-Based Weigh-in-Motion



The Cardinal SWIM series of slow speed in-motion vehicle scales offers the ideal combination of accuracy and speed. The SWIM in-motion scale's welded steel platform is typically the length of a traffic lane and is contained within a single framework. Each platform is supported by four Cardinal stainless steel analog compression load cells to weigh each axle end of a vehicle as it travels across the scale. The weighing

platform is approximately 14 feet in width and 3 ft in length and is constructed of a smooth steel plate. The weighbridge is mounted in a pit less than 1.5 feet deep, so very little space is needed for this axle weighing truck scale. The extremely stiff and rigid weighbridge, coupled with four 50,000-pound capacity Cardinal strain gauge compression load cells, results in a higher resonant frequency allowing more efficient filtering of spurious weight signals.

- Includes four 50,000 pound capacity NTEP and OIML certified stainless steel compression load cells. These are the same load cells used in many of Cardinal's legendary static vehicle scales
- Rigidly-checked, fully-welded heavy capacity steel weighbridge
- Includes NTEP and OIML certified weight indicator
- Speeds up to 10 mph with 1 percent error rates
- Integral load cell stainless steel junction box
- Available accessories include axle sensors, vehicle classifier, traffic control, license plate readers, DOT readers, and custom software



SLOW-SPEED WIM

Cardinal Scale reserves the right to improve, enhance or modify features and specifications without prior notice. All registered trademarks are the property of their respective owners.

### **Applications:**

- Freight Terminals
- Commercial Fleet Axle Weight Monitoring
- Axle Compliance
- Ports (SOLAS Regulations)

#### **SOLD BY:**

Cardinal Scale Manufacturing Co.
102 E. Daugherty, Webb City, MO 64870 USA
Ph: 417-673-4631 or 800-441-4237 • Fax: 417-673-2153
www.CardinalScale.com