



# SCRAPPER

RECYCLING TRUCK SCALE



LEGAL FOR TRADE

## Economical NTEP Truck Weighing

- Excellent Low-Cost Truck Scale for Mid-Sized Trucks and Pick-up Trucks Pulling Trailers
- Truck Scale Capacities up to 45 Tons and 52.5 ft. Lengths (25 Ton CLC)
- Designed Specifically for Scrap Yards, Recycling Centers, and Landscaping Facilities
- High-Tensile-Strength, Corrosion-Resistant Concrete Decks - Optional Guide Rails



Precast Concrete Medium-Duty Full-Length Truck Scales

# SCRAPPER

RECYCLING TRUCK SCALE

Cardinal Scale's Scrapper series truck scales are engineered for scrap yards, recycling centers, and landscaping facilities requiring a medium-duty NTEP legal-for-trade scale at an economical price. The Scrapper utilizes the proven PSC high-tensile-strength, pre-stress concrete deck weighbridge that is 10 ft. wide with lengths up to 52 ft. long.

The Scrapper series comes in capacities ranging from 25 tons up to 45 tons (25-ton CLC), providing an excellent low-cost scale for mid-sized trucks and pick-up trucks pulling trailers. Cardinal Scale offers single-source convenience and quality construction utilizing stainless steel model CBC compression load cells. The lifting lugs and a foundation template are included with each PSC truck scale order to ease installation.

- **Factory-Poured Precast Concrete Scale Decks**
- **Stainless Steel Load Cells**
- **NTEP Certified for Commercial Use**
- **Low-Profile Design with Easy Load Cell Access**
- **Total Concrete Deck Construction Resistant to Corrosion and Modular in Design**
- **Rodent Protection Steel Conduit Standard**
- **Single Source Convenience for Indicators, Guide Rails, Remote Displays, and Software**

Model Number	Platform Size	Overall Capacity	Concentrated Load Capacity	Number of Sections	Shipping Weight
2517-PSC	17.5 ft L x 10 ft W	25 tons	25 tons	2	15,000 lb
3535-PSC	35 ft L x 10 ft W	35 tons	25 tons	3	28,000 lb
4552-PSC	52.5 ft L x 10 ft W	45 tons	25 tons	4	41,000 lb

**Deck Thickness:** 7.25 inches

**Under-Weighbridge Clearance:** 7.5 inches

**NTEP COC:** 12-063

**Load Cells:** Cardinal model CBC stainless steel compression

**Options:** Guide rails, weight indicators, remote displays, unattended kiosks, and vehicle recording systems

Cardinal Scale reserves the right to improve, enhance or modify features and specifications without prior notice. All registered trademarks are the property of their respective owners.

**Cardinal**  
 Cardinal Scale Manufacturing Co.  
 203 E. Daugherty, Webb City, MO 64870 USA  
 Ph: 417-673-4631 or 800-441-4237 • Fax: 417-673-5001  
[www.CardinalScale.com](http://www.CardinalScale.com)

**Mobile: [m.cardinalscale.com](http://m.cardinalscale.com)**

**SOLD BY:**