



## LARGER-THAN-LIFE OFFROAD VEHICLE WEIGHING

- Massive 150-Ton Capacity | High 70-Ton CLC
- Available in Impervious Hydraulic or Electronic
- Durable Baked-on, Anti-Corrosion Powder Paint

If you're in the business of moving mountains one truckload at a time, then Cardinal's extreme-duty YUKON® is your truck scale of choice. Designed and built specifically for the mining industry and offroad vehicle weighing, the NTEP legal-for-trade YUKON® features an amazingly-high, 70-ton concentrated load capacity with extra-thick, heavy-duty steel deck plate. Featuring extra-wide concrete or steel decks, the YUKON® employs Cardinal's compression-type, environmentally-sealed (IP68) stainless steel load cells built in the company's state-ofthe-art load cell manufacturing facility in Webb City, MO.

# The SCALE for MOVING MOUNTAINS



### **REMOTE DISPLAYS**

Cardinal's SB500 displays giant 5-inch-high digits for long range visibility. Features Stop/Go - Red/Green lights for traffic coordination.



## **UNATTENDED OPERATIONS**

Lower operating costs by incorporating Cardinal's unmanned vehicle weight management to your truck scale operation. Available with barcode badge reader or proximity badge reader, and/or ticket printer.

#### PERIPHERAL EQUIPMENT

Cardinal offers a selection of optional accessories, including side rails, weight indicators, remote displays, printers, and vehicle weight management software to complete your YUKON® truck scale operation.

Cardinal Scale offers the widest range of truck scale technology available from one scale manufacturer: portable axle, weigh-in-motion, self-contained, electro-mechanical, electronic, and hydraulic.

## **EXTRA-THICK DECK**

Cardinal's YUKON® features heavy-duty extra-thick steel deck plate. Optional 8-inch concrete decks are also available.



SUPERIOR STEEL STRENGTH FOR HEAVY-DUTY LOADS

## LONG-LASTING PAINT FINISH

ardina

The durable baked-on, anti-corrosion powder paint provides a long-lasting quality truck scale appearance for unmatched environmental protection.





## LARGER-THAN-LIFE OFFROAD TRUCK SCALE





## EXTREMELY-HIGH CONCENTRATED LOAD CAPACITY

The YUKON® features an amazingly-high 70-ton Concentrated Load Capacity, or CLC. Concentrated Load Capacity is a term defining a scale's ability to weigh loads concentrated in a relatively small area to replicate loads applied by a truck's axles. The large trucks used in mining and excavation support their heavy loads on a relatively few number of axles thus concentrating the total load in a few small footprints on the scale platform. A substantial CLC rating is necessary to ensure that a loading pattern produced by trucks like these is accurately measured.





Available in 12, 14, and 16-foot wide extra-large scale platforms to easily accommodate off-road vehicles.



Cardinal model SST Hydraulic Load Cells



Cardinal

Cardinal model SCA Electronic Load Cells

n



## **STAINLESS STEEL LOAD CELLS**

The YUKON<sup>®</sup> employs Cardinal's compression-type, environmentally-sealed (IP68) stainless steel load cells, built in the company's state-of-the-art load cell manufacturing facility in Webb City, Missouri. Available in impervious hydraulic or electronic scale types.

## ELECTRONIC MODELS

HYDRAULIC MODELS

CAPACITIES: 150 Tons CLC: 70 Tons

**CAPACITIES:** 150 Tons **CLC:** 70 Tons

12-FT-WIDE STEEL DECKS		
MODEL	SCALE LENGTH	SHIPPING WT.
15060-CY12	60 ft.	38,600 lb
15070-CY12	70 ft.	45,000 lb
15080-CY12	80 ft.	51,500 lb

 $\Pi$ N

14-FT-WIDE STEEL DECKS		
MODEL	SCALE LENGTH	SHIPPING WT.
15060-CY14	60 ft.	45,000 lb
15070-CY14	70 ft.	52,500 lb
15080-CY14	80 ft.	60,000 lb

16-FT-WIDE STEEL DECKS		
MODEL	SCALE LENGTH	SHIPPING WT.
15060-CY16	60 ft.	51,500 lb
15070-CY16	70 ft.	60,000 lb
15080-CY16	80 ft.	68,600 lb

12-FT-WIDE CONCRETE DECKS		
MODEL	SCALE LENGTH	SHIPPING WT.
15060-CY12-C	60 ft.	23,500 lb
15070-CY12-C	70 ft.	27,350 lb
15080-CY12-C	80 ft.	31,300 lb

14-FT-WIDE CONCRETE DECKS		
MODEL	SCALE LENGTH	SHIPPING WT.
15060-CY14-C	60 ft.	27,350 lb
15070-CY14-C	70 ft.	31,900 lb
15080-CY14-C	80 ft.	36,450 lb

12-FT-WIDE STEEL DECKS		
MODEL	SCALE LENGTH	SHIPPING WT.
H15060-CY12	60 ft.	39,000 lb
H15070-CY12	70 ft.	45,500 lb
H15080-CY12	80 ft.	52,000 lb

14-FT-WIDE STEEL DECKS		
MODEL	SCALE LENGTH	SHIPPING WT.
H15060-CY14	60 ft.	45,500 lb
H15070-CY14	70 ft.	53,100 lb
H15080-CY14	80 ft.	60,700 lb

16-FT-WIDE STEEL DECKS		
MODEL	SCALE LENGTH	SHIPPING WT.
H15060-CY16	60 ft.	52,000 lb
H15070-CY16	70 ft.	60,700 lb
H15080-CY16	80 ft.	69,400 lb

12-FT-WIDE CONCRETE DECKS		
MODEL	SCALE LENGTH	SHIPPING WT.
H15060-CY12-C	60 ft.	23,900 lb
H15070-CY12-C	70 ft.	27,850 lb
H15080-CY12-C	80 ft.	31,800 lb

14-FT-WIDE CONCRETE DECKS		
MODEL	SCALE LENGTH	SHIPPING WT.
H15060-CY14-C	60 ft.	27,850 lb
H15070-CY14-C	70 ft.	32,500 lb
H15080-CY14-C	80 ft.	37,150 lb

## CERTIFICATIONS

The YUKON® Truck Scale meets or exceeds Class III/IIIL, 10,000 division accuracy requirements in accordance with NIST Handbook 44. A Certificate of Compliance Number **09-061** has been issued under the National Type Evaluation Program (NTEP) of the National Conference on Weights and Measures.



Cardinal Scale reserves the right to improve, enhance or modify features and specifications without prior notice. All registered trademarks are the property of their respective owners.



**SOLD BY:**